

Warnings and Caution

1. Do not connect the AC power cord when the power supply is in use. Doing so may cause damage to your components.
 2. Do not place this power supply in a high humidity and/or temperature environment.
 3. High voltages exist in the power supply. Do not open the power supply case unless you are an authorized service technician or electrician. Doing so will void the warranty.
 4. PSU should be powered by the source indicated on the rating label.
 5. All warranties and guarantees will be voided, if failure to comply with any of the warnings and cautions covered in this manual.

Components Check

- LITEPOWER power supply unit - AC power cord

- User manual - Mounting screw x 4

Power Connector Introduction

Cable	Main Power Connector (24Pin)	ATX 12V Connector (4+4Pin)	PCI-E Connector (6+2Pin)	SATA Connector (5 Pin)	Peripheral Connector (4Pin)	Floppy Connector (4Pin)
P/N						
LTP-0650P-2	1	1	2	5	6	1
LTP-0650P-F						
LTP-0550P-2	1	1	2	5	4	1
LTP-0550C-F						
LTP-0450P-2	1	1	2	4	4	1
LTP-0450C-F						
LTP-0350P-2	1	1	0	3	3	1
LTP-0350C-F						

Installation Steps

Note: Make sure that your system is turned off and unplugged.

Disconnected the AC power cord from your old power supply.

1. Open your computer case; please refer to the direction in your case manual.

2. Install the PSU into the case with the four screws provided.

If your motherboard requires a 24pin Main Power connector, please connect the 20+4pin Main Power connector to the motherboard.

If your motherboard only requires a 20pin Main Power connector, please detach the 4pin connector from the 20+4pin Main Power connector and connect it to the motherboard.

For motherboard that only requires a 4pin ATX 12V (CPU) connector, please detach a 4pin connector from the 4+4pin ATX 12V connector and connect it to the motherboard.

(Either one of the 4pin from the 4+4pin ATX 12V connector will work)

5. Connect other peripheral power connectors to devices such as hard drives, optical drives, etc.

6. Connect any devices that may use the 4 pin peripheral connectors. i.e; hard drives, CD/DVD drives or case fans.

7. If your graphic card requires PCI-E power connector, please connect corresponding PCI-E connector instructed by your graphic card's user manual. Please note the power supply utilizes a 6+2pin PCI-E connector that can be effectively used as a single 8pin or 6pin PCI-E connector. To use it as a 8pin PCI-E connector, please detach the 2pin connector from the 6+2pin connector.

DIES WIRD IHR SYSTEM BESCHÄDIGEN.

8. Schließen Sie die Computergehäuse und verbinden Sie das Wechselstromkabel mit dem entsprechenden Eingang des Netzteils.

Output Specification

P/N	AC INPUT	DC OUTPUT				
		+3.3V	+5V	+12V	-12V	+5VSB
LTP-0650P-2	Input Voltage: 230V Input Current: 9A Frequency: 50Hz - 60Hz	23A	17A	48A	0.5A	2.5A
LTP-0650P-F	Input Voltage: 100V - 240V Input Current: 12A Frequency: 50Hz - 60Hz	110W	576W	6W	12.5W	
LTP-0550P-2	Input Voltage: 230V Input Current: 7A Frequency: 50Hz - 60Hz	21A	16A	38A	0.5A	2.5A
LTP-0550P-F	Input Voltage: 110V / 220V Input Current: 10A Frequency: 50Hz - 60Hz	105W	456W	6W	12.5W	
LTP-0450P-2	Input Voltage: 230V Input Current: 5A Frequency: 50Hz - 60Hz	20A	14A	33A	0.5A	2.5A
LTP-0450P-F	Input Voltage: 110V / 220V Input Current: 8A Frequency: 50Hz - 60Hz	100W	396W	6W	12.5W	
LTP-0450C-F	Input Voltage: 110V / 220V Input Current: 8A Frequency: 50Hz - 60Hz	450W				
LTP-0350P-2	Input Voltage: 230V Input Current: 4A Frequency: 50Hz - 60Hz	16A	13A	26A	0.5A	2.5A
LTP-0350P-F	Input Voltage: 110V / 220V Input Current: 6A Frequency: 50Hz - 60Hz	90W	312W	6W	12.5W	
LTP-0350C-F	Input Voltage: 110V / 220V Input Current: 6A Frequency: 50Hz - 60Hz	350W				

Total Protection

- Over Voltage Protection
- Over Power Protection
- Short Circuit Protection

Voltage Source Protection Point

+3.3V 3.76-4.3V Max.

+5V 5.74-7V Max.

+12V 13.4-15.6V Max.

EMI & SAFETY

P/N	EMI Regulatory & SAFETY Standards
LTP-0350P-2 / LTP-0450P-2 / LTP-0550P-2 / LTP-0650P-2	CE, TUV SUD, CB, EAC, RCM certified.
LTP-0350C-F / LTP-0450C-F / LTP-0550C-F / LTP-0650P-F	CE, TUV SUD, CB, FCC, UL, S Mark, EAC, BSMI and RCM certified.

Environments

Operating temperature +5°C to +35°C

Operating humidity 20% to 85%, non-condensing

MTBF > 100, 000 hours

Trouble-Shooting

If the power supply fails to function properly, please follow the troubleshooting guide before application for service:

1. Is the power cord plugged properly into electrical outlet and into the power supply AC inlet?

2. Please make sure the I/O switch on the power supply is switched to I position.

3. Please make sure all power connectors are properly connected to all the devices.

4. If connected to a UPS unit, is the UPS on and plugged in?

If the power supply is still unable to function properly after following the above instruction, please contact our local store or T1 branch office for after sales service. You may also refer to Thermaltake's website for more technical support: thermaltake.com

Wenn das Netzteil nicht richtig funktioniert, befolgen Sie bitte zuerst die Anleitungen der Störungsbeseitigung, bevor Sie sich an den Kundendienst wenden:

1. Ist das Stromkabel richtig in den elektrischen Ausgang (Steckdose) und den elektrischen Eingang für Wechselstrom eingesteckt?

2. Stellen Sie sicher, dass der Ein/Aus-Schalter (I/O) auf dem Netzteil auf der Position "I" steht.

3. Stellen Sie sicher, dass alle Anschlüsse richtig mit den Einheiten verbunden sind.

4. Sind Sie angeschlossen an eine UPS? Ist das UPS eingeschaltet und angeschlossen?

Wenn das Netzteil nach Überprüfung der oben angegebenen Fehlerursachen immer noch nicht richtig funktioniert, wenden Sie sich bitte an Ihren lokalen Händler oder die T1 Niederlassung für Unterstützung. Sie können sich auch auf der Website von Thermaltake unter thermaltake.com für weitere technische Unterstützung.

English

1. Do not connect the AC power cord when the power supply is in use. Doing so may cause damage to your components.
 2. Do not place this power supply in a high humidity and/or temperature environment.
 3. High voltages exist in the power supply. Do not open the power supply case unless you are an authorized service technician or electrician. Doing so will void the warranty.
 4. PSU should be powered by the source indicated on the rating label.
 5. All warranties and guarantees will be voided, if failure to comply with any of the warnings and cautions covered in this manual.

Components Check

- LITEPOWER power supply unit - AC power cord

- User manual - Mounting screw x 4

Power Connector Introduction

Cable	Main Power Connector (24Pin)	ATX 12V Connector (4+4Pin)	PCI-E Connector (6+2Pin)	SATA Connector (5 Pin)	Peripheral Connector (4Pin)	Floppy Connector (4Pin)
P/N						
LTP-0650P-2	1	1	2	5	6	1
LTP-0650P-F						
LTP-0550P-2	1	1	2	5	4	1
LTP-0550C-F						
LTP-0450P-2	1	1	2	4	4	1
LTP-0450C-F						
LTP-0350P-2	1	1	0	3	3	1
LTP-0350C-F						

Installation Steps

Note: Make sure that your system is turned off and unplugged.

Disconnected the AC power cord from your old power supply.

1. Open your computer case; please refer to the direction in your case manual.

2. Install the PSU into the case with the four screws provided.

If your motherboard requires a 24pin Main Power connector, please connect the 20+4pin Main Power connector to the motherboard.

If your motherboard only requires a 20pin Main Power connector, please detach the 4pin connector from the 20+4pin Main Power connector and connect it to the motherboard.

For motherboard that only requires a 4pin ATX 12V (CPU) connector, please detach a 4pin connector from the 4+4pin ATX 12V connector and connect it to the motherboard.

(Either one of the 4pin from the 4+4pin ATX 12V connector will work)

5. Connect other peripheral power connectors to devices such as hard drives, optical drives, etc.

6. Connect any devices that may use the 4 pin peripheral connectors. i.e; hard drives, CD/DVD drives or case fans.

7. If your graphic card requires PCI-E power connector, please connect corresponding PCI-E connector instructed by your graphic card's user manual. Please note the power supply utilizes a 6+2pin PCI-E connector that can be effectively used as a single 8pin or 6pin PCI-E connector. To use it as a 8pin PCI-E connector, please detach the 2pin connector from the 6+2pin connector.

DIES WIRD IHR SYSTEM BESCHÄDIGEN.

8. Schließen Sie die Computergehäuse und verbinden Sie das Wechselstromkabel mit dem entsprechenden Eingang des Netzteils.

Output Specification

P/N	AC INPUT	DC OUTPUT				
		+3.3V	+5V</th			

繁體中文

警告和注意事項

1. 請勿使用電源供應器時拔下 AC 電源線。否則，可能會損壞元件。
2. 請勿將電源供應器放置在高溫或高溫環境中。
3. 電源供應器內存有高壓。非經授權的維修技術或電工，請勿打開電源供應器的外殼。否則可能導致固件失效。
4. 應按指定標籤上的指示供電。
5. 若未遵照本手冊中的任何警告與注意事項，將導致所有保證和保證失效。

檢查元件

- LITEPOWER 電源供應器
- 交流電源線
- 使用說明書
- 安裝螺絲 x 4

電源接頭介紹

產品 料號	接頭	主電源接頭 (24 针)	4+4 針 CPU 電源接頭	6+2 針 PCI-E 接頭	5 針 S-ATA 接頭	4 針遭連接 裝置接頭	4 針軟碟機 接頭
LTP-0650P-2	1	1	2	5	6	1	
LTP-0650P-F	1	1	2	5	6	1	
LTP-0550P-2	1	1	2	5	4	1	
LTP-0550C-F	1	1	2	4	4	1	
LTP-0450P-2	1	1	2	4	4	1	
LTP-0450C-F	1	1	2	4	4	1	
LTP-0350P-2	1	1	0	3	3	1	
LTP-0350C-F	1	1	0	3	3	1	

安裝步驟

註：請確定系統已關閉且已斷電。斷開 AC 電源線與舊電源供應器的連接。

1. 打開電腦殼；請參閱機殼隨附的使用手冊。
2. 使用附的四顆螺絲將 PSU 裝入機殼。
3. 若主板需使用 24 針主電源接頭，請卸下 20+4 針主電源接頭連接至主機板。若主機板僅需使用 20 針主電源接頭，請卸下 20+4 針主電源接頭上的 4 針接頭，然後僅將 20 針接頭連接至主機板。
4. 對於需使用 4 針 ATX 12V(CPU)接頭的主機板，請卸下 4+4 針 ATX 12V 接頭上的 4 針接頭，然後將 4 針接頭連接至主機板。(4+4 針 ATX 12V 接頭上的任何 4 針接頭都可)
5. 使用前的 SATA 纜線將 SATA 裝置（如適用）連接至電源供應器。SATA 裝置包括硬碟機、CD/DVD 光碟機。
6. 可選任何可能使用 4 針遭連接裝置的裝置。例如，硬碟機、CD/DVD 光碟機或機殼風扇。
7. 若顯示卡需使用 PCI-E 電源接頭，請連接顯示卡使用手冊的說明，連接對應的 PCI-E 接頭。請注意，電源供應器需用獨特的 6+2 針 PCI-E 接頭，可有效用作單人 8 針或 6 針 PCI-E 接頭。若要將其作為 6 針接頭使用，請卸下 6+2 針接頭上的 2 針接頭。
8. 請勿將 PCI-E 繩線插入 CPU 電源連接。這將會壞壞您的系統。
9. 關閉電腦機殼，並將 AC 電源線連接至電源供應器 AC 電源插孔。

輸出規格

料號	交流輸入	+3.3V	+5V	+12V	-12V	+5VSB	直流通輸出
----	------	-------	-----	------	------	-------	-------

LTP-0650P-2	輸入電壓: 230V 輸入電流: 9A 頻率: 50Hz - 60Hz	23A	17A	48A	0.5A	2.5A	110W	576W	6W	12.5W
LTP-0650P-F	輸入電壓: 100V - 240V 輸入電流: 12A 頻率: 50Hz - 60Hz						650W			

料號	交流輸入	+3.3V	+5V	+12V	-12V	+5VSB	直流通輸出
----	------	-------	-----	------	------	-------	-------

LTP-0550P-2	輸入電壓: 230V 輸入電流: 7A 頻率: 50Hz - 60Hz	21A	16A	38A	0.5A	2.5A	105W	456W	6W	12.5W
LTP-0550C-F	輸入電壓: 110V / 220V 輸入電流: 10A 頻率: 50Hz - 60Hz						550W			

料號	交流輸入	+3.3V	+5V	+12V	-12V	+5VSB	直流通輸出
----	------	-------	-----	------	------	-------	-------

LTP-0450P-2	輸入電壓: 230V 輸入電流: 5A 頻率: 50Hz - 60Hz	20A	14A	33A	0.5A	2.5A	100W	396W	6W	12.5W
LTP-0450C-F	輸入電壓: 110V / 220V 輸入電流: 8A 頻率: 50Hz - 60Hz						450W			

料號	交流輸入	+3.3V	+5V	+12V	-12V	+5VSB	直流通輸出
----	------	-------	-----	------	------	-------	-------

LTP-0350P-2	輸入電壓: 230V 輸入電流: 4A 頻率: 50Hz - 60Hz	16A	13A	26A	0.5A	2.5A	90W	312W	6W	12.5W
LTP-0350C-F	輸入電壓: 110V / 220V 輸入電流: 6A 頻率: 50Hz - 60Hz						350W			

料號	交流輸入	+3.3V	+5V	+12V	-12V	+5VSB	直流通輸出
----	------	-------	-----	------	------	-------	-------

LTP-0350P-F	輸入電壓: 230V 輸入電流: 4A 頻率: 50Hz - 60Hz	16A	13A	26A	0.5A	2.5A	90W	312W	6W	12.5W
LTP-0350C-F	輸入電壓: 110V / 220V 輸入電流: 6A 頻率: 50Hz - 60Hz						350W			

料號	交流輸入	+3.3V	+5V	+12V	-12V	+5VSB	過電壓保護
----	------	-------	-----	------	------	-------	-------

LTP-0650P-2	輸入電壓: 230V 輸入電流: 9A 頻率: 50Hz - 60Hz	3.76-4.3V	5.74-7V	7.4-7.7V	5.74-7V	3.76-4.3V	滿載的 110%~170%
LTP-0650P-F	輸入電壓: 100V - 240V 輸入電流: 12A 頻率: 50Hz - 60Hz	3.76-4.3V	5.74-7V	7.4-7.7V	5.74-7V	3.76-4.3V	滿載的 110%~170%

料號	交流輸入	+3.3V	+5V	+12V	-12V	+5VSB	過功率保護
----	------	-------	-----	------	------	-------	-------

LTP-0650P-2	輸入電壓: 230V 輸入電流: 9A 頻率: 50Hz - 60Hz	3.76-4.3V	5.74-7V	7.4-7.7V	5.74-7V	3.76-4.3V	滿載的 110%~170%
LTP-0650P-F	輸入電壓: 100V - 240V 輸入電流: 12A 頻率: 50Hz - 60Hz	3.76-4.3V	5.74-7V	7.4-7.7V	5.74-7V	3.76-4.3V	滿載的 110%~170%

料號	EMI 與安全	EMI 規範與安全標準
----	---------	-------------

LTP-0350P-2 / LTP-0450P-2 / LTP-0550P-2 / LTP-0650P-2	取得 CE - TUV SUD - CB - EAC - RCM 認證 -	CE - TUV SUD - CB - EAC - RCM 認證 -
LTP-0350C-F / LTP-0450C-F / LTP-0550C-F / LTP-0650P-F	取得 CE - TUV SUD - CB - FCC - UL - S Mark, EAC - BSMI - RCM 認證 -	CE - TUV SUD - CB - FCC - UL - S Mark, EAC - BSMI - RCM 認證 -

料號	EMI 與安全	EMI 規範與安全標準
----	---------	-------------

LTP-0350P-2 / LTP-0450P-2 / LTP-0550P-2 / LTP-0650P-2	取得 CE - TUV SUD - CB - EAC - RCM 認證 -	CE - TUV SUD - CB - EAC - RCM 認證 -
LTP-0350C-F / LTP-0450C-F / LTP-0550C-F / LTP-0650P-F	取得 CE - TUV SUD - CB - FCC - UL - S Mark, EAC - BSMI - RCM 認證 -	CE - TUV SUD - CB - FCC - UL - S Mark, EAC - BSMI - RCM 認證 -